

| 1 | Pump casing | 10 | Ventfilterplug | 19 | Locking gasket | 28 | Mechanical seal |
|---|-----------------|----|------------------|----|----------------------|----|--------------------------|
| 2 | Impeller | 11 | Bearing bracket | 20 | Support foot | 29 | Gasket |
| 3 | Gasket | 12 | Lubricating ring | 21 | Constant-level-oiler | 30 | Pump cover |
| 4 | Shaft sleeve | 13 | Circlip | 22 | Bearing cover | 31 | Impeller seal ring |
| 5 | O-ring | 14 | Ball bearing | 23 | Dust-proof ring | 32 | Seal ring of pump casing |
| 6 | O-ring | 15 | Bearing cover | 24 | Shaft sleeve | 33 | Impeller seal ring |
| 7 | Mechanical seal | 16 | Dust-proof ring | 25 | Sealing cover | 34 | Seal ring of pump casing |
| 8 | Seal cover | 17 | Shaft | 26 | O-ring | 35 | Threaded insert |
| 9 | Ball bearing | 18 | Bearing nut | 27 | Pipe | 36 | Impeller nut |